






RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA164P/MS.

TOYOTA TARAGO

(Filter is located behind glove box)



GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz

RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA164P/MS.


TOYOTA TARAGO

(Filter is located behind glove box)

- ① The cabin air filter is located behind the glove compartment.




- ② Open the glove compartment & remove the support arm by sliding arm of the pin.




- ③ Apply pressure to the front and rear of glove compartment as shown to disengage the claws, open all the way.




- ④ To remove filter assembly, push on both ends of the cover as shown and pull out.



- ⑤ Noting flow direction remove old filter, insert new filter (Note flow direction) then refit all previously removed parts.



- ⑥



Dispose of used filter correctly.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz