

# 24 LITRE THERMO COOLER INSTRUCTIONS



**RIDGE** GEAR  
ADVENTURE  
**RYDER**

## CONTENTS

General Safety.....	3
Performance & Function .....	4
Assembly & Parts .....	4
Operating Instructions .....	5
Maintenance & Troubleshooting.....	6
Specifications .....	7
Warranty .....	7



**IMPORTANT:** It is important that you read these instructions carefully and understand the operation and safety features of this appliance

## GENERAL SAFETY

- Connect the device only as follows:
  - When connecting the power cables supplied with the appliance for connection to 12V DC or 240V AC power source
- The appliance shall not be exposed to rain
- When removing the plug from the socket, do not pull on the power cable
- If the 12V DC or 240V AC cable is damaged it must be replaced with the same type & rated cable in order to avoid operating problems
- If the device shows visible damage, do not use
- Repairs on this device may only be executed by an approved repair agent
- In the case of required repairs or warranty please contact the Customer Service line PH: 1300 555 197
- Disconnect the supply cable after each use and before cleaning and servicing
- Make sure the ventilation slots are not covered or obstructed at any time during operation
- Check that the voltage indicated on the type plate corresponds to that of the energy supply
- The appliance is not suitable for the transport of corrosive or solvent based substances!
- Food may only be stored in its original packaging or in suitable containers



### ELECTRICAL DEVICES ARE NOT TOYS!

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of this appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

## SAFETY WHEN OPERATING THE APPLIANCE

- Before use ensure the power cords are serviceable & dry
- Do not place the appliance in the proximity of open flames or other heat sources (heaters, strong solar rays, gas ovens etc.)
- Do not fill any liquids or ice into the interior of the appliance
- Protect the appliance and cables against heat and moisture
- Ensure your hands are dry before handling the plug or switching on the appliance
- Super Retail Group or Supercheap Auto are not liable for damages which are caused by non-intended use or incorrect operation
- This product is suitable for camping use
- The appliance shall not be exposed to rain
- This appliance is not intended to be used in household and similar applications such as
  - staff kitchen areas in shops, offices and other working environments;
  - farm houses and by clients in hotels, motels and other residential type environments;
  - bed and breakfast type environments;
  - catering and similar non-retail applications.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance

## PERFORMANCE & FUNCTION

The Ridge Ryder thermocooler is suitable for mobile use; it is not intended to be used as a fridge/freezer. It can cool goods down to max 25°C below ambient temperature or warm up to a max of 65°C. The performance may differ depending on conditions such as voltage input, thermal load, ventilation, number of times the cabinet is opened and closed, temperature of goods inside unit etc.

Note: Minimum temperature is dependent on the surrounding ambient/external temperature.

For example if it is 30°C outside the cooler's minimum temperature will be approximately 5°C

The thermocooler is equipped with an automatic voltage change over function that will select 240V power over 12V power; if 240V power is not available then the 12V power is automatically selected.

## ASSEMBLY AND PARTS



Large easy to read digital control panel



Easy to clean liner



Large fans for efficient performance




12V and 240V cables included



Easy to access power socket


## OPERATING INSTRUCTIONS

**Step 1:** Select the required Power Cable and connect to the appliance and suitable power source




**Step 2:** Power On


- Press power button on display




- Press the temp set button display will flash



- Use the up/down buttons to select desired temperature




- A green light will illuminate on display for cooling & red light for warming modes



## ADJUSTING TO HEAT OR COOL

**Step 1:**

- Use the up/down buttons to select desired temperature
- A fan sound will occur when heat or cool mode activated.




**PLEASE NOTE:** ONCE DESIRED TEMPERATURE SET, DISPLAY WILL REVERT SHOWING CURRENT TEMPERATURE OF CABINET.

## TURN OFF

**Step 1:**

- Press power button to turn unit off

NOTE: Fans may run for up to 30 seconds after turning off.



## HINTS & TIPS

- Place the appliance on stable ground when in use
- Ensure the appliance is located in a shady spot for effective cooling
- For effective use it is best to cool the unit overnight with nothing inside of it
- Let warm foods cool down first before placing them in the appliance
- If using the appliance to store medicine, please check if the cooling capacity of the device corresponds to the requirements of the respective medication

## MAINTENANCE AND TROUBLESHOOTING



### CLEANING

Disconnect the power cable from the power source before cleaning

#### CAUTION!

Using warm soapy water and mild detergents wipe down all internal and external surfaces of the appliance taking care that water does not enter any vents or electrical connections.

DO NOT submerge or rinse the appliance under water, in a bowl or sink

DO NOT use abrasive cleaners or bleach

### DISPOSAL

Place the packaging material in the appropriate recycling waste bins wherever possible.

If you wish to dispose of the appliance, ask your local recycling centre or specialist dealer for details about how to do this in accordance with the applicable disposal regulations.

### TROUBLE SHOOTING

FAULT	POSSIBLE CAUSE	SUGGESTION
The appliance does not appear to function and the internal fan cannot be heard	Check that the display is on Check the input power source	<ul style="list-style-type: none"> <li>• Check all cable connections repair or replace as required</li> <li>• Check the fuse located in the cigarette lighter tip is operational and not damaged Glass Fuse 5mm x 20mm F10A/250V</li> </ul> <p><b>On DC/12V:</b></p> <ul style="list-style-type: none"> <li>• Check that the ignition switch is turned on allowing power to the 12V accessory socket. Many accessory sockets require the engine to be running</li> <li>• Check the 12V socket fuse in the vehicle or on your power supply is not damaged.</li> <li>• Try any alternative 12V power supply.</li> </ul> <p><b>ON AC/240V:</b></p> <ul style="list-style-type: none"> <li>• Check that the lead is connected correctly</li> <li>• Check that the power is turned on</li> </ul>
The appliance does not appear to be operating however the display is illuminated and the internal fan can be heard	The ambient temperature is above the maximum level of 35°C degrees	<ul style="list-style-type: none"> <li>• Check the temperature and move to a cooler location</li> <li>• Ensure that the vents are not blocked or obstructed</li> <li>• Remove some of the produce to reduce the thermal mass</li> </ul>
The appliance does not appear to be operating & the internal fan cannot be heard	The Thermo-Electric system is defective	Call Customer Service on 1300 555 197 for assistance
	The Integrated Electrical System is defective	
The appliance is not reaching set temperature	Appliance only capable of cooling 25°C degrees below ambient temperature or warm up to a max of 65°C degrees	Move appliance to cooler area or change temperature setting



## SPECIFICATIONS

<b>Model</b>	RR0056 Thermo-Cooler 24L		
<b>Capacity - Gross</b>	24 L		
<b>Rated Voltage</b>		<b>Mode</b>	<b>Rating</b>
<b>Input DC</b>	12V	Cool	70W ± 10%
		Heat	60W ± 10%
<b>Input AC</b>	220-240V 50-60Hz	Cool	55W ± 10%
		Heat	63W ± 10%
<b>Climate Category</b>	T		

### WARRANTY

This product is guaranteed against defects for a period of 12 months from date of purchase.

This warranty is provided by Supercheap Auto Pty Ltd ACN 085 395 124 (Supercheap Auto) of 6 Coulthards Ave, Strathpine, QLD 4500. PO Box 344 Strathpine, QLD 4500. Phone: +61 (0)7 3482 7900, Fax: + 61 (0)7 3205 8522. The warranty is not transferable to a subsequent customer if the product is sold by the original customer during the warranty period. If a defect appears in the manufacture or assembly of the product before the end of the warranty period and Supercheap Auto find the product to be defective in materials or workmanship than Supercheap Auto will, in its sole discretion either;

- Replace or repair the product or defective part of the product free of charge; or
  - Have the product or defective part of the product replaced or repaired by a qualified repairer free of charge
- Supercheap Auto reserves the right to replace a defective part of the product with parts and components of similar quality, grade and composition where an identical part is not available. Refurbished parts may be used to repair the product

### WARRANTY CLAIMS

- To claim under this warranty, take this product to the Front Service Desk of your nearest Supercheap Auto store. For store locations, visit [www.supercheapauto.com.au](http://www.supercheapauto.com.au) (AUS) or [www.supercheapauto.co.nz](http://www.supercheapauto.co.nz) (NZ)
- Any warranty claim must be accompanied by proof of purchase; additional information may be requested of you to process your claim. Should you not be able to provide proof of purchase with a receipt or bank statement, identification showing your name, address and signature may be required to process your claim
- The product may need to be sent for testing to assess the defect before determining any claim. Faults or defects cause by product modification, misuse and abuse, normal wear and tear or failure to follow user instructions are not covered under this warranty

### CONSUMER RIGHTS

- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
- You are entitled to have the goods replaced if the goods fail to be of an acceptable quality and the failure does not amount to major failure.
- Any expenses incurred relating to the return of this product to store will normally have to be paid by you. For more information contact your nearest Supercheap Auto store.
- The benefits to the consumer given in this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods and services to which this warranty relates.

PLU: 577077  
CODE: RR0057  
Manufactured and packaged for  
SRGS PTY LTD  
ABN 23 113 230 050  
6 Coulthards Ave, Strathpine  
Queensland 4500, Australia  
PO Box 344 Strathpine, Queensland 4500  
Phone: +61 (0)7 3482 7900  
Fax: +61 (0)7 3205 8522  
**MADE IN CHINA**