

# TOOLPRO

## V12 2 Speed Drill Driver Skin

Instruction Manual

PLU 573245



**Important** - Please read these instructions fully before operating or maintaining your Drill driver

These instructions contain important information that will help you get the best from your tool, ensuring it remains safe to operate.

# Contents

Safety Information.....	3
In The Box.....	8
Accessories.....	8
Operating Information.....	9
Trouble shooting.....	12
Maintenance.....	13
Technical Data.....	13
Warranty.....	14

# Safety Information

**Important** - Please read these instructions fully before starting assembly

## Warning Symbols



To reduce the risk of injury, Please read the instruction manual



Warning



Wear ear protection



Wear eye protection



Wear dust mask



Indoor use only



Do not expose to rain or water



Do not burn



Waste electrical products must not be disposed of with household waste. Please recycle where facilities exist. Check with your local authorities or retailer for recycling advice.



Li-Ion



Li-Ion

Li-ion battery. This product has been marked with a symbol relating to 'separate collection' for all battery packs and battery pack. It will then be recycled or dismantled in order to reduce the impact on the environment. Battery packs can be hazardous for the environment and for human health since they contain hazardous substances.



T 2A

Fuse



Positive terminal



Negative terminal



Read the operator's manual



Double insulation



RCM marking

# Safety Information

**Important** - Please read these instructions fully before starting assembly

## **General Power Tool Safety Warnings**



**WARNING: Read all safety warnings and all instructions.** Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

### **Save all warnings and instructions for future reference.**

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

#### **1) Work area safety**

- a) Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- c) Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

#### **2) Electrical safety**

- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- c) Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- e) When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

#### **3) Personal safety**

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection.** Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

# Safety Information

**Important** - Please read these instructions fully before starting assembly

## **General Power Tool Safety Warnings**

- d) **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
  - e) **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
  - f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
  - g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- 4) Power tool use and care**
- a) **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
  - b) **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
  - c) **Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
  - d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
  - e) **Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
  - f) **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
  - g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- 5) Battery tool use and care**
- a) **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
  - b) **Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
  - c) **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or a fire.

# Safety Information

**Important** - Please read these instructions fully before starting assembly

## General Power Tool Safety Warnings

d) **Under abusive conditions, liquid may be ejected from the battery; avoid contact.** If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

### 6) Service

**Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

## Safety points for your battery operated drills & drill driver

**1. Hold power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring.** Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

## Additional safety instructions for your Battery Charger

1. Before charging, read the instructions.
2. For charge Li-ion battery pack only.
3. Do not charge a leaking battery.
4. Do not use chargers for works other than those for which they are designed.
5. Before charging, ensure your charger is matching the local AC supply.
6. The charging device must be protected from moisture.
7. Do not use the charging device in the open.
8. Do not short out the contacts of battery or charger.
9. Respect the polarity "+/-" when charging.
10. Do not open the unit and keep out of the reach of children.
11. Ensure that the connection between the battery charger and battery is correctly positioned and is not obstructed by foreign bodies.
12. Keep battery charger's slots free of foreign objects and protect against dirt and humidity. Store in a dry and frost-free place.
13. When charging batteries, ensure that the battery charger is in a well-ventilated area and away from inflammable materials. Batteries can get hot during charging. Do not overcharge any batteries. Ensure that batteries and chargers are not left unsupervised during charging.
14. Do not recharge non-rechargeable batteries, as they can overheat and break.
15. Longer life and better performance can be obtained if the battery pack is charged when the air temperature is between 18°C and 24°C. Do not charge the battery pack in air temperatures below 4.5°C, or above 40.5°C. This is important as it can prevent serious damage to the battery pack.
16. Charge only battery pack of the same model provided by manufacturer and of models recommended by manufacturer.

# Safety Information

**Important** - Please read these instructions fully before starting assembly

## **Safety Warnings for battery pack**

- a) **Do not dismantle, open or shred cells or battery pack.**
- b) **Do not short-circuit a battery pack. Do not store battery packs haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by conductive materials.** When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- c) **Do not expose battery pack to heat or fire. Avoid storage in direct sunlight.**
- d) **Do not subject battery pack to mechanical shock.**
- e) **In the event of battery leaking, do not allow the liquid to come into contact with the skin or eyes.** If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- f) **Seek medical advice immediately if a cell or battery pack has been swallowed.**
- g) **Keep battery pack clean and dry.**
- h) **Wipe the battery pack terminals with a clean dry cloth if they become dirty.**
- i) **Battery pack needs to be charged before use. Always refer to this instruction and use the correct charging procedure.**
- j) **Do not maintain battery pack on charge when not in use.**
- k) **After extended periods of storage, it may be necessary to charge and discharge the battery pack several times to obtain maximum performance.**
- l) **Battery pack gives its best performance when it is operated at normal room temperature (20 °C ± 5 °C).**
- m) **When disposing of battery packs, keep battery packs of different electrochemical systems separate from each other.**
- n) **Recharge only with the charger specified by manufacturer.** Do not use any charger other than that specifically provided for use with the equipment. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- o) **Do not use any battery pack which is not designed for use with the equipment.**
- p) **Keep battery pack out of the reach of children.**
- q) **Retain the original product literature for future reference.**
- r) **Remove the battery from the equipment when not in use.**
- s) **Dispose of properly.**

# In The Box

## Parts



- ① Keyless chuck
- ② Torque adjustment ring
- ③ Forward/Reverse rotation control
- ④ Soft grip handle
- ⑤ Battery pack release button
- ⑥ Battery pack (sold separately)
- ⑦ On/off switch
- ⑧ Sight light
- ⑨ Two-speed gear control
- ⑩ Battery capacity indication
- ⑪ Belt clip

## Accessories

Belt clip

1



# Operating Instructions

## Intended Use

This tool is intended for driving in and loosening screws as well as for drilling in wood, metal and plastic.



**NOTE:** Before using the tool, read the instruction book carefully.

## 1. CHARGING PROCEDURE

### BEFORE PUTTING INTO OPERATION

#### CHARGING THE BATTERY PACK (SEE FIG A)

##### NOTE:

- The battery in your new tool is not charged when it leaves the plant. Therefore it must be full charged before using the first time.**
- Do not use any charger other than that specifically provided for use with the equipment.
- If the battery pack is very hot you must remove your battery pack from the charger and allow time for the battery to cool down before recharging.
- Please charge the battery to reach full or no less than half charge before storage. If the tool will not be used for long periods of time, charge the battery every 3-6 months.

### CHARGING PROCEDURE

- Plug the charger into an appropriate outlet.
- Place the battery pack into the charger.
- When charging is completed, unplug the charger and remove the battery pack.



**WARNING:** When battery charge runs out after continuous use or exposure to direct sunlight or heat, allow time for the battery to cool down before re-charging to achieve the full charge.

A	LED INDICATOR		SITUATION
	Green	Red	
	Blinking light	No light	Stand by
	No light	Solid light	Charging
	Solid light	No light	Charging is complete
	Blinking light	Blinking light	Battery pack is too hot or cold (charging will begin automatically when battery reaches correct charging temperature)
	No light	Blinking light	Damaged or faulty battery pack

# Operating Instructions

## 2. INSTALLING AND REMOVING THE BATTERY PACK (SEE FIG B)

### a) TO REMOVE THE BATTERY PACK

Press the Battery Pack Release Button (5) firmly first and then pull the Battery Pack out from your tool.

### b) TO INSTALL THE BATTERY PACK

Push the fully charged Battery Pack onto the tool with sufficient force until it clicks into position.

## 3. ON/OFF SWITCH (SEE FIG C)

Press the On/Off switch (7) to start and release it to stop your drill.

The on/off switch (7) is fitted with a brake function which stops your chuck immediately when you quickly release the switch.

It is also a variable speed switch that delivers higher speed and torque with increased trigger pressure. Speed is controlled by the amount of switch trigger depression.

**WARNING:** Do not operate for long periods at low speed because excess heat will be produced internally.


## 4. SWITCH LOCK (SEE FIG C)

The switch trigger can be locked in the OFF position. This helps to reduce the possibility of accidental starting when not in use. To lock the switch trigger, place the rotation control (3) in the center position.

## 5. REVERSIBLE (SEE FIG C)

For drilling and screw driving use forward rotation marked “<” (rotation control (3) is moved to the left). Only use reverse rotation marked “>” (rotation control (3) is moved to the right) to remove screws or release a jammed drill bit.

**WARNING:** Never change the direction of rotation when the chuck is rotating, wait until it has stopped!



# Operating Instructions

## 6. TWO-SPEED GEAR CONTROL (SEE FIG C)

The drill has a two-speed gear control [9] designed for drilling or driving at LOW (mark is 1) or HIGH (mark is 2) speeds. A slide switch is located on top of the drill to select either LOW or HIGH speed. When using the drill in the LOW speed range, the speed will decrease and the drill will have greater power and torque. When using the drill in the HIGH speed range, the speed will increase and the drill will have less power and torque.

### Gear I

Low speed range: for screwdriving or working with Large diameter drill

### Gear II

High speed range: for working with small diameter drill

**WARNING:** To prevent gear damage, always allow the chuck to come to a complete stop before changing the direction of rotation or the two-speed gear control.

## 7. CHUCK ADJUSTMENT (SEE FIG D)

Rotate the front section of the chuck to open the jaws. Insert the drill bit, taking care to ensure the drill bit is in the centre of the chuck jaws. Rotate the front section of the chuck in the opposite direction until the drill bit is firmly clamped.

## 8. TORQUE ADJUSTMENT (SEE FIG E)

(Screw driving force of your drill driver)

The torque is adjusted by rotating the torque adjustment ring. The torque is greater when the torque adjustment ring [2] is set on a higher setting. The torque is less when the torque adjustment ring is set on a lower setting.



Make the setting as follows:

---

1-7 for driving small screws

---

8-14 for driving screws into soft material

---

15-20 for driving screws into soft and hard material

---

 for heavy drilling

---

# Operating Instructions

## 9. USING THE SIGHT LIGHT

To turn on the light [8], press the on/off switch [7] and make sure the forward/reverse rotation control [3] is on right/left position. When you release the on/off switch, the light will be off.

LED lighting increases visibility - great for dark or enclosed area.

## 10. BATTERY CAPACITY INDICATION

Your tool is equipped with Battery Capacity Indication [10]. Press the On/Off Switch [7], the Battery Capacity Indication [10] will light up to show the amount of charge left in the battery.

## 11. BELT CLIP

Insert the Belt Clip [11] into the tool. The belt clip can be clipped on your belt or pocket, etc.

## 12. DRILLING

To activate the drill function (For drilling metal wood or plastic), turn the torque adjustment ring on the drill position. Depress the trigger to start the tool. Move the drill bit into the workpiece, applying only enough pressure to keep the bit cutting. Do not force or apply side pressure to elongate a hole.

**HINTS:** When drilling in metal, only use HSS drill bits in good condition. Always use a magnetic bit holder (not included) when using short screwdriver bits. When screw-driving, apply a small quantity of liquid soap or similar to the screw threads to ease insertion. For metal surfaces use a centre punch to mark the desired hole.

### NOTE:

If your tool stops working when drilling a hole automatically, this is the overload electrical protection for battery. Completely release the trigger to let the battery cool down and start the tool again.

# Trouble shooting

**NOTE:** Remove plug and/or battery carrying out any adjustment, servicing or maintenance.

Problem	Cause	Remedy
Drill does not work.	1. Flat battery. 2. Forward/Reverse not selected.	1. Charge battery. 2. Select forward or reverse.
Chuck does not close or grip.	1. Lock screw loose. 2. Swarf in chuck.	1. Open chuck fully and tighten screw (left hand thread). 2. Clean inside chuck.




# Maintenance

Your tool requires no additional lubrication or maintenance.

There are no user serviceable parts in your power tool. Never use water or chemical cleaners to clean your power tool. Wipe clean with a dry cloth. Always store your power tool in a dry place. Keep the motor ventilation slots clean. Keep all working controls free of dust. Occasionally you may see sparks through the ventilation slots. This is normal and will not damage your power tool.

## Technical Data

Technical Data Table

Voltage	12 V 
No load speed	0-400/0-1300/min
Number of clutch positions	20+1
Max torque	30 N.m
Chuck capacity	1.5-10 mm
Charger protection class	 /II
Charger input	100-240V~50/60Hz, 35W
Charger output	10.8--14.4V  2000mA
Machine weight	0.825kg (without battery)
Optional battery	2.0/4.0Ah Samsung Li-ion battery packs
Charging time	1hr for 2.0Ah battery pack 2hr for 4.0Ah battery pack

# WARRANTY

This product is guaranteed against defects a period of (3 years) from date of purchase. This warranty is provided by SRGS PTY LTD ABN 23 113 230 050 of 751 Gympie Rd Lawnton QLD 4501 Ph (07) 3482 7500. Supercheap Auto will offer a repair, replacement product or store credit if the product is assessed as being defective during the warranty period.

To claim under this warranty, take this product to the Front Service Desk of your nearest Supercheap Auto store. For store locations, visit [www.supercheapauto.com.au](http://www.supercheapauto.com.au) (AUS) or [www.supercheapauto.co.nz](http://www.supercheapauto.co.nz) (NZ). You will need your receipt or proof of purchase. Additional information may be requested of you to process your claim. Should you not be able to provide proof of purchase with a receipt or a bank statement, identification showing your name, address and signature may be required to process your claim.

This product may need to be sent to the manufacturer to assess the defect before determining any claim. Faults or defects caused by product modification, misuse and abuse, normal wear and tear or failure to follow user instructions are not covered under this warranty.

Your warranty is subject to the following conditions:

- Battery packs are guaranteed for a 12 month period only.
- The tool has not been misused, abused, neglected, altered, modified or repaired by anyone other than an authorized service centre.
- Only genuine ToolPRO accessories and parts have been used on or with the product.
- The tool has been subjected to fair wear and tear.
- The tool has not been used for trade or professional purposes.
- The tool has not been used for rental purposes.
- The tool has not sustained damage through foreign objects, substances or accidents.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any expenses incurred relating to the return of this product to store will normally have to be paid by you. For more information contact your nearest Supercheap Auto store.

The benefits to the consumer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods and services to which this warranty relates.