

14.5x21cm

封底 封面


AIR SPOT SAND BLASTING GUN INSTRUCTION MANUAL



Manufactured and packaged for SRGS PTY LTD ABN 23 113 230 050
751 Gympie Road, Lawnton, Queensland 4501, Australia

BLACKRIDGE

Air Spot Sand Blasting Gun Instruction Manual



AIR SPOT SAND BLASTING GUN



PLU 572896

WARRANTY

This product is guaranteed against defects for a period of (12 months) from date of purchase. This warranty is provided by SRGS PTY LTD ABN 23 113 230 050 of 751 Gympie Rd Lawnton QLD 4501 Ph (07) 3482 7500. Supercheap Auto will offer a repair, replacement product or store credit if the product is assessed as being defective during the warranty period.

To claim under this warranty, take this product to the Front Service Desk of your nearest Supercheap Auto store. For store locations, visit www.supercheapauto.com.au (AUS) or www.supercheapauto.co.nz (NZ). You will need your receipt or proof of purchase.

Additional information may be requested of you to process your claim. Should you not be able to provide proof of purchase with a receipt or a bank statement, identification showing your name, address and signature may be required to process your claim.

This product may need to be sent to the manufacturer to assess the defect before determining any claim. Faults or defects caused by product modification, misuse and abuse, normal wear and tear or failure to follow user instructions are not covered under this warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any expenses incurred relating to the return of this product to store will normally have to be paid by you. For more information contact your nearest Supercheap Auto store.

The benefits to the consumer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods and services to which this warranty relates.

CONTENTS

INTRODUCTION
SAFETY GUIDELINE DEFINITIONS
IMPORTANT SAFETY INSTRUCTIONS
OPERATING INSTRUCTIONS
MAINTENANCE INSTRUCTIONS
TROUBLESHOOTING

SAFETY GUIDELINE - DEFINITIONS

This spot blast kit is used for the removal of rust spots on car body panels, door, boot and bonnet edges and provides a very focussed rust removal area using the special rubber nozzle sleeves.

WARNING

Please read and understand all safety precautions in this manual before operating. Failure to comply with instructions in this manual could result in personal injury, property damage and/or invalidate your warranty. The manufacturer WILL NOT be liable for any damage due to failure to follow these instructions.

This manual contains information that is important for you to know and understand. This information relates to protecting YOUR SAFETY and PREVENTING EQUIPMENT PROBLEMS. To help you recognize this information, we use the following symbols. Please read the manual and pay attention to these sections.

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Observe all safety points that follow this symbol to avoid possible injury or death.

2

3

DANGER Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and/or property damage.

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

WARNING To reduce the risk of electric shock, fire, and injury to persons, read all the instructions before using the tool. You must also read the compressor manual and follow all compressor safety instructions.

GENERAL SAFETY

WARNING RISK OF ELECTRIC SHOCK, FIRE, AND/OR INJURY. Keep the work area clean and well lit. Cluttered benches and dark areas increase the risks of electric shock, fire, and injury to persons. Place cleaning rags and other flammable waste materials in a secured metal container. The container should be disposed of properly in accordance with local authority regulations.

WORK AREA SAFETY

WARNING RISK OF EXPLOSION AND/OR FIRE. Do not operate the tool in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. The tool is able to create sparks resulting in the ignition of the dust or fumes.

RISK OF INJURY. Keep bystanders, children, and pets away while operating the tool. Distractions are able to result in the loss of control of the tool.

PERSONAL SAFETY

WARNING RISK OF INJURY. Stay alert. Watch what you are doing and use common sense when operating the tool. Do not use the tool while tired or under the influence of drugs, alcohol, or medication. A moment of attention lapse while operating the tool increases the risk of injury to persons.

RISK OF INJURY. Dress properly. Do not wear loose clothing or jewellery. Contain long hair. Keep hair, clothing, and gloves away from moving parts. Loose clothes, jewellery, or long hair increase the risk of injury to persons as a result of being caught in moving parts.

RISK OF INJURY. Avoid unintentional starting. Be sure the trigger is off before connecting to the air supply. Do not carry the tool with your finger on the trigger or connect the tool to the air supply with the trigger on. Do not carry the tool by the hose.

IMPORTANT SAFETY INSTRUCTIONS

WARNING RISK TO BREATHING/INHALATION HAZARD. Always wear approved, properly fitting face mask or respirator and work in a well ventilated area when using tools that generate dust. Some dust created contains chemicals hazardous to health.

WARNING RISK OF INJURY. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.

WARNING RISK OF EYE INJURY. Always wear approved safety goggles when using an air tool. Air powered equipment and power tools are capable of propelling materials such as metal particles and other debris at high speed which could result in serious eye injury.

WARNING RISK OF ELECTRIC SHOCK. Explore the workplace to avoid contact with hidden wiring. Thoroughly investigate the workplace for possible hidden wiring before performing work. Contact with a "live" wire will also make exposed metal parts of the tool "live" and shock the operator.

TOOL USE AND CARE SAFETY

WARNING RISK OF INJURY. Use clamps or another practical way to secure and support the workplace to a stable platform. Holding the workplace by hand or against the body is unstable and is able to lead to loss of control.

RISK OF INJURY. Do not use the tool if the trigger does not turn the tool on or off. Any tool that cannot be controlled with the trigger is dangerous and must be repaired.

4

5

RISK OF INJURY. Disconnect the tool from the air source before making any adjustments, changing accessories, or storing the tool. Such preventative safety measures reduce the risk of starting the tool unintentionally.

RISK OF INJURY. Store the tool when it is idle, out of reach of children and other untrained persons. A tool is dangerous in the hands of untrained users.

IMPORTANT SAFETY INSTRUCTIONS

WARNING RISK OF BURSTING AND/OR INJURY. Check for misalignment or binding of moving parts, breakage of parts and any other condition that affects the tool's operation. If damaged, have the tool serviced before using. Do not operate the tool with the protective guarding removed or damaged. Replace the tool or have it repaired by an authorized service centre. Many accidents are caused by poorly maintained tools or air hose. There is a risk of bursting if the tool is damaged.

RISK OF BURSTING AND/OR INJURY. Check for damaged air hose. Keep the air hose away from heat, oil, and sharp edges. Inspect the air hose periodically and replace it if it becomes worn or damaged.

RISK OF BURSTING AND/OR INJURY. Use compressed air regulated to a maximum pressure at or below the rated pressure of any attachments. Never operate the tool over 90 PSI (6.2 BAR). Exceeding the maximum pressure rating of tools or accessories could cause an explosion resulting in serious injury.

WARNING RISK OF INJURY. Use only accessories that are designed for the specific tool. Use of an accessory not intended for use with the specific tool, increases the risk of injury to persons.

TOOL USE AND CARE SAFETY

WARNING RISK OF INJURY. Tool service must be performed only by qualified repair personnel.

WARNING RISK OF INJURY. When servicing a tool, use only identical replacement parts. Use only authorized parts.

AIR SOURCE SAFETY

WARNING RISK OF BURSTING AND/OR INJURY. Never connect to an air source that is greater than 90 PSI (6.2 BAR). Over pressurizing the tool may result in bursting, abnormal operation, breakage of the tool, or serious injury to persons. Use only clean, dry, regulated compressed air at the rated pressure or within the rated pressure range as marked on the tool. Always verify prior to using the tool that the air source has been adjusted to the rated air pressure or within the rated air pressure range.

WARNING RISK OF EXPLOSION AND INJURY. Never use oxygen, carbon dioxide, combustible gases or any bottled gas as an air source for the tool. Such gases are capable of explosion and serious injury to persons.

OPERATING INSTRUCTIONS

To begin using the tool:

- As a standard practice, drain water from the air compressor receiver and air lines prior to use each day (reference your compressor operator manual for detailed instructions). IMPORTANT: Installation of an air filter to remove water/ oil is recommended. Failure to do so will cake the abrasive material and clog the sandblasting gun, causing the gun to not operate.
- Turn on the air compressor and allow it build up pressure.
- Adjust the air compressor's regulator or the supplier line regulator to 90 PSI (6.2 BAR).

Assembly:



• Spot blast components



• Fit the grit recycling bag

6


7



• Twist off the grit container




• Pour dry abrasive grit into the container




• Select the correct spot blast nozzle for the work in hand




• Flat Panel Spot Blaster



• Door Edge Nozzle



• Corner nozzle



• Narrow strip nozzle



• Fit nozzle

8

9

Spot Blast Gun is now ready for connecting to the air line and use

Usage guidelines:

- When de-rusting steel components, use aluminium oxide recyclable abrasive
- When de-oxidising aluminium component, use glass bead abrasive material
- Pour the appropriate abrasive into the spot blast gun container (the spot blast kit is supplied with aluminium oxide abrasive)
- Fit the recycle collecting bag under the nozzle guide
- Select and fit the appropriate rubber nozzle for the job in hand
- Connect the air hose
- Set the air pressure by adjusting the air outlet pressure regulator to a maximum of 90 PSI (6.2 BAR)
- Ensure that you are wearing the correct protective clothing, safety goggles and mask.
- Hold the rubber nozzle firmly against the workpiece and squeeze the trigger. Release the trigger before removing the rubber nozzle from the workpiece. Squeezing the trigger will operate the spot blast gun, releasing the trigger will stop it.
- Having released the trigger, remove the gun from the workpiece to inspect the job. Repeat procedure from step 8 until the job is complete.
- Spent abrasive is collected in the recycle collecting bag and may be poured back into the guns container for re-use.
- Do not leave abrasive in the gun after use. Always thoroughly clean the spot blast gun before storing. The abrasive material must be kept dry at all times.

WARNING Always disconnect the sandblaster from the air supply before changing accessories, relocating or performing any maintenance.

WARNING Risk of Injection. The high pressure and abrasive materials that are used during sandblasting can penetrate skin and cause serious injury. Wear approved safety glasses or face shield, gloves and a approved respirator during operation. Always direct spray away from self and others or serious injury could occur.

WARNING Ensure that you are wearing the correct protective clothing, safety goggles and mask.

MAINTENANCE INSTRUCTIONS

After each use: Clean the surface with an air blaster or medium bristle brush to remove any remaining abrasive material.

WARNING Always disconnect the tool from the air supply before performing any maintenance.

Changing Nozzles:

Periodically (depending on the amount of use), the nozzle will become worn, causing the spray to become irregular or to stop.

- Disconnect the sandblaster from the air supply.
- Remove the nozzle lock nut and carefully pull out the nozzle.
- Gently insert a new nozzle, replace the nozzle nut.

TROUBLESHOOTING

SYMPTOM	POSSIBLE CAUSE(S)	CORRECTIVE ACTION
Sputtering-vacuum leak	Damaged o-ring	Replace o-ring.
Gun does not spray material	Wet or damp material	Replace wet abrasive material with dry material. Damp material can be reused after it has dried.
	Water in air lines	Drain compressor receiver and install and in-line filter.
Sputtering-air/material leaking at nozzle area	Damaged o-ring.	Replace o-ring.
	Loose syphon	Tighten nozzle assembly
Material slow out of gun	Clogged syphon tube	Reduce the air pressure to 30 PSI and hold the gun nozzle tip against a flat surface. Pull the trigger to force any stuck material back out of the syphon tube.
	Wet or damp material	Replace wet abrasive material with dry material. Damp material can be reused after it has dried.
Sputtering-low vacuum	Worn nozzle	Replace nozzle.
	Abrasive material build up around nozzle	Remove and clean nozzle.

10